

NOTES ABOUT THE CHART:
 *X in the miter (MTR) column may require a miter cut and glue to create a corner moulding.
 •Use of T201, T202 and T203 may be recommended for removal and reinstallation of exposed edge parts.
 •GGG Corp provides this chart as a referral guide only.



2011

UNIVERSAL MOULDING APPLICATION CHART

THOUSANDS OF APPLICATIONS

Distributed By:

Moulding Tools

GTOOL500

Cut mitered corners easily.
 Precise mitered & straight cuts.

GGLUE

Use GGLUE to quickly bond the moulding together. Apply sparingly to the cut edge of the moulding. Press together and hold. GGLUE is especially formulated to bond Gold Glass Mouldings fast and is available in black.

GTOOL201

for use with the T-201

Original Line	T-105B	T-107B	T-108B	T-109B	T-105BFL	T-107BFL
Economy® Line	ET-105B	ET-107B	ET-108B	ET-109B	ET-105BFL	ET-107BFL
<p>These mouldings are available in Original or Economy®</p> 5/8" (17mm) 3/4" (20mm) 1" (25mm) 1 1/4" (31mm) FEATURE LINE 5/8" (17mm) FEATURE LINE 3/4" (20mm)						
<p>Other Mouldings Available</p> T-100B 1/4" (7mm) T-101B 3/8" (10mm) T-301B 5/8" (16mm) T-110 3/4" (20mm) T-120BC CHROME 5/8" (17mm)						
<p>Available in Original or Economy®</p> T-201 or ET-201 Glass 5/16" Urethane Aggressive Adhesive Rubber Moulding with adhesive T-202 or ET-202 Glass 7/32" Urethane Aggressive Adhesive Closed Cell Foam Mouldings go around tight radius corners on quarter & back glasses. T-203 or ET-203 Glass 9/32" Urethane Aggressive Adhesive ET-204 Glass 3/8" Urethane Aggressive Adhesive Rubber Moulding with adhesive						

Sample Boards

Original T-BRD
 Economy® ET-BRD

YEAR	MODEL	W/S	B/G	QTR	MTR
1984	ACURA				
1997	1993	CL	T105B	T107B	
1986	1993	Integra	T105B		
2001	2006	MDX			T202
2007	2011	MDX	T107B		
2007	2011	RDX	T107B		
2005	2008	RL		T202	
2002	2006	RSX	T108B		
1996	1999	SLX	T108B		
1995	2011	TL	T105B	T107B	X
2000	2011	TSX	T105B		X
1988	1992	80	T100B	T100B	
1988	1995	90	T100B	T100B	
1988	1994	100	T100B	T100B	
1989	1991	200	T100B		
1984	1988	5000	T100B	T100B	
1999	2011	A4/RS4/S4	T201	T203	X
2008	2011	A5/Q5/RS5/S5	T201		
1995	1998	A6	T100B	T100B	
2003	2011	AG/RS6/S6	T202	T201	
2004	2011	A8L	T202		
2002	2011	Allroad Quattro	T202	T201	
2007	2011	Q7	T202		
2001	2003	S8	T202		
2007	2008	S8		T201	X
2000	2000	TT Coupe	T202		
1990	1994	V8 Quattro	T100B	T100B	
1992	2005	318/328	T107B		
2004	2005	5 Series	T105B		
2004	2010	645/650		T201	X
2002	2009	7 Series	T107B		
1999	2002	M Coupe / Roadster	T108B		
2000	2006	M3		T101B	
2000	2010	M5		T202	X
2004	2006	X3	T107B		
1999	2002	Z3 Coupe	T108B		
1982	2005	Century	T107BFL	T107BFL	
2008	2011	Electra	T105B	T107B	
2008	2011	Enclave	T202		X
2005	2007	LaCrosse/Allure	T101B	T101B	
2010	2011	LaCrosse/Allure	T201		X
1986	1991	LeSabre	T105BFL	T107BFL	
2004	2005	LeSabre	T105B	T101B	
2006	2010	Lucerne	T101	T201	X
2011	2011	Lucerne	T201		X
1985	1988	Park Avenue	T105B	T107B	
1985	1988	Park Avenue	T105B	T107B	
1997	2006	Park Avenue	T108B		
1987	2004	Regal	T107BFL	T107BFL	
1979	1999	Riviera	T105BFL		
1991	1996	Roadmaster	T107B		
1982	1987	Skyhawk	T105B	T105B	
1989	1998	Skyline	T107B		
1985	1987	Somerset Regal	T105B	T105B	
1997	2001	Catera	T108B		
1982	1988	Camaro	T105BFL	T105B	
2003	2007	CTS	T101B	T201	
2008	2011	CTS	T201		X
1985	1993	Deville	T105B	T107B	
1994	1999	Deville	T108B		
1979	1985	Eldorado	T105BFL		
1980	1994	Eldorado	T105B	T105B	
1999	2006	Escalade	T108B		
2007	2011	Escalade/ESV/EXT	T201		
1985	1996	Fleetwood	T105B	T105B	
1985	1992	Fleetwood (RWD)	T107B		
1985	1995	Hearshe	T105B		
1980	1991	Seville	T107B	T105B	
1993	1993	Sixty Special	T105B		
2004	2009	SRX		T201	T202
2010	2011	SRX	T202		X
2005	2011	STS	T201	T202	
1985	2005	Astro	T107B		X
2002	2006	Avalanche	T108B		
2007	2011	Avalanche	T201		X
2007	2011	Aveo	T301B	T301B	X
2009	2010	Aveo 5	T301B		
1987	1996	Beretta	T105B		
1997	2002	C Series Med Duty	T108B		
1982	2002	Camaro	T107B		
1994	1996	Caprice	T107B		
1982	1984	Cavalier	T105B	T105B	
1995	2005	Cavalier	T105B	T101B	
1982	1988	Celebrity	T105B	T107B	
1981	1987	Chevette	T105B	T105B	
2005	2011	Chevyenne	T100B	T100B	
2004	2005	Classic	T100B		
2005	2011	Cobalt 4DR	T201	T201	X
2005	2011	Cobalt Coupe	T201	T202	
2004	2011	Colorado	T109B		T202
1994	1996	Corica	T105B		
1999	2004	Corvette	T107B		
2010	2011	Cruze	T203		
1987	1987	EI Camino	T107BFL		
2005	2009	Equinox	T107B		T202
2010	2011	Equinox	T107B		
1981	1996	G Series Van	T109B		
2006	2011	HHR	T202		
1987	2005	Impala	T105BFL		
2006	2010	Impala	T201		X
1990	1996	Impala SS	T107B		
1990	1996	Lumina	T107BFL		
1990	1996	Lumina APV	T107B		
1997	2003	Malibu	T301B	T301B	
2004	2011	Malibu	T201	T201	T202
1987	2005	Master	T105B	T105B	
1987	2009	Monte Carlo	T105BFL		
2000	2005	Monte Carlo	T105BFL		
1999	2000	Pickup	T108B		
1983	1994	S10 Blazer	T107BFL		
1995	2005	S10 Blazer	T107BFL		
1982	1992	S10 Pickup	T107BFL		
1994	2003	S10 Pickup	T107BFL		
1995	1996	Series 50-65-70	T108B		
1999	2006	Silverado	T107B		
2003	2006	Silverado	T201		
2003	2006	Suburban	T107B		
2007	2011	Suburban	T201		
1995	2006	Tahoe	T107B		
2007	2011	Tahoe	T201		
1998	1998	Tracker	T105B		
1999	2006	Tracker	T101B		
2002	2009	TrailBlazer / EXT	T105B		
2005	2004	300	T100B		
2005	2010	300	T301B		
2008	2008	300		T201	X
1996	2000	Cirrus	T100B	T107B	
1993	2005	Concorde	T107B	T107B	
1991	1996	Executive	T105B		
2000	2000	Grand Voyager	T100B		
1990	1993	Imperial	T105B		
1984	1986	Laser	T107BFL		
1985	1995	Lebaron	T105B	T105B	
2000	2007	LHS	T107B	T107B	
1999	2001	LHS	T108B		
1988	1997	New Yorker	T107B		
1985	1988	New Yorker (FWD)	T105B		
2004	2007	Pacifica	T101B		
1994	2000	Sebring	T100B	T107BFL	
2001	2006	Sebring	T100B	T107BFL	
1985	1995	Town & Country	T105B	T108B	
1996	2007	Town & Country	T100B	T202	
2000	2007	Voyager	T100B	T202	
1988	2002	Lanos	T100B	T107B	
1985	1988	600	T105B		
1985	1989	Aries	T105B		
1996	2000	Avenger	T105B	T108B	
1994	1995	Caravan	T105B	T108B	
1996	2007	Caravan	T100B		
2006	2010	Charger	T301B	T301B	
1985	1996	Colt	T107B	T100B	
1984	1984	Colt Vista	T107B		
1989	2000	Dakota Pickup	T108B		

YEAR	MODEL	W/S	B/G	QTR	MTR
1984	1993	Daytona		T107BFL	
1998	2000	Durango	T108B		
1988	1993	Dynasty	T105B	T105B	
1987	1995	Grand Caravan	T105B	T108B	
1996	2007	Grand Caravan	T100B	T202	
1993	1997	Intrepid	T107B	T107B	
1998	2005	Intrepid	T100B		
1985	1989	Lancer	T105B	T105B	
2005	2008	Magnus	T100B		
1990	1992	Monaco	T107B	T108B	
1995	2005	Neon	T107B		
2007	2011	Nitro		T107B	
1988	1994	Shadow	T107B		
1989	1995	Spirit	T105B	T105B	
1991	1996	Sleath	T107B		
1995	2000	Stratus	T100B	T105B	
1994	2003	Van	T108B		
1988	1989	Medallion	T107B		
1988	1992	Premier	T107B	T108B	
1989	1996	Summit	T107B		
1990	1994	Talon	T107B	T107B	
1995	1998	Talon		T108B	
1993	1997	Vision	T108B	T107B	
1997	1997	Aerostar	T107BFL	T105BFL	
1994	1997	Aspire	T107B		
1995	2000	Contour	T108B		
2000	2011	Crown Victoria	T107BFL		X
1992	2008	Edge	T107BFL		X
2007	2011	Escape	T101B		X
1989	2002	Escort	T105BFL	T107BFL	
1997	2003	Expedition	T100B		
2008	2009	Expedition	T109B		
2010	2011	Expedition	T101B		
1997	2008	F Series/150	T100B		
2009	2012	F Series/150	T201		X
2005	2007	Five Hundred	T101B	T201	X
2000	2007	Focus	T101B		X
2000	2010	Focus	T101B		
2004	2007	Freestar	T109B		
2006	2011	Freestar	T100B		
2001	2012	Lobo	T201		
1994	2004	Mustang	T107B	T107B	
2007	2011	Mustang	T101B		X
1988	1997	Probe	T105BFL		
1986	2001	Taurus	T107BFL	T107BFL	
2000	2007	Taurus	T107B	T201	X
2008	2009	Taurus	T203		
2010	2011	Terrain	T108B		
1994	1997	Thunderbird	T108B		
2010	2011	Transit	T101B		
1995	2003	Windstar	T108B	T107B	
2001	2003	ZX2	T105BFL		
1995	1997	Metro	T107B	T105B	
1989	1997	Prizm	T105B	T105B	
1985	1989	Spectrum	T105B		
1990	1993	Storm	T107B		
1989	1997	Tracker	T105B		
1997	2002	C Series Med Duty	T108B		
1987	1987	Caballero	T107BFL		
2004	2011	Canyon	T109B		T202
1995	2007	Cherokee	T105BFL		
1981	1986	G Series Van	T109B		
1996	2001	Jimmy	T105BFL		
1995	2002	Pickup	T108B		
1983	1994	S15 Jimmy	T105BFL		
1982	1990	S15 Pickup	T105BFL		
1985	2				